


## Digital Dual Sim II - Installation Manual



1. Please touch a water tab or s.th similar first for grounding reasons

2. Cut the simcards

First possibility (as shown on the pictures)

Stick the adhesive label (4) on the simcard and cut along the visible line with a good pair of scissors. If everything is correct, the simcards will fit tightly into the holder (1).



Second possibility (as shown on the pictures)

You can just place one of the "resume cards" (3) on your simcard and draw around the hole with a pencil. This way you are saving the adhesive label (4). Cut around the line with a pair of scissors afterwards.



**3. Put your cut simcards face down into the holder (1)**



If you have stuck the adhesive label (4) onto the simcard before, please take it off first..Make sure that the cut simcards are small enough and that the contact parts are clean.


**4. Close the holder (1), by fitting the cover (2) carefully on the holder (1)**



**5. Put the adapter in your cellphone (as seen in the Universal Dual Sim Demo video)**

**6. Start your phone.**

Sim 1 is active. You will find a new entry in your menu under "Connections" or "Accessories" or "Extras" or directly in the menu. The entry is called "STK" or "Dual Simcard" or "Simselect":



Here you can choose the simcard.(Sim 1, Sim 2)  
You can also switch on / switch off the BOTH ONLINE \* function (Switch on /off)

This new function lets the phone change simcards automatically every 3-7 minutes, if you do not put in a pin-code.  
It can be handy when you are busy and still want to be reachable on 2 numbers.

**7. You can program a call divert if you want to be reachable on both numbers all the time.**

You can use the single simcards with the simple adapters.

If the adapter does not work please check first if both simcards work separately and change them in the adapter slots.

ATTENTION:  
WE DO NOT GIVE ANY GUARANTEE FOR CUTTING THE SIMCARDS